

TRU-VU OMNISCREEN MULTI-COLOR

COMPATIBILITY GUIDE

Unit	Version (V)	Release (R)	Compatible	Upgradeable	Notes
Paradise XL/TC	any	n/a	No	No	
	2	n/a	No	No	
PAL	3	(no letter)	No	Yes	1, 2, 3
		A	No	Yes	1, 3
		B	Yes		4
		C	Yes		
PAL36 (with CES)	1	(no letter)	No	Yes	1, 2, 3
		A	No	Yes	1, 3
		B	Yes		4
		C	Yes		
Delight	1	A	No	Yes	1
		B	No	Yes	1
		C	Yes		
		D	Yes		

Notes

- 1) Requires Hardware Upgrade
- 2) Requires Firmware Upgrade
- 3) Upgrading may cause noise issue (a fix may not be available)
- 4) Unit may have noise issue (known partial fix available)

SERIAL NUMBER

VyyymmRxxxxAA

(V) Version (yy) Production Year (mm) Production Month,
 (R) Release (xxxx) Unique ID (AA) Product ID

- Older units may not have the Release letter.
- Version 1 PALs and Paradise XL/TC units used a different serial number format.

OTHER LABELS

The PAL compatibility also applies to ALERT, Brain Buddy, and NeuroAdvantage Trainer units.

The Delight compatibility also applies to NeuroCore and LifeLogix units.